



DRW. DR100001

SPARE-PARTS

Select language English

SPARE-PARTS KIT TABLE

SPARE-PARTS

SCM 4" PLUS

PUMP MODEL

RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	SCM 4" PLUS 40/57	SCM 4" PLUS 40/90	SCM 4" PLUS 40/120	SCM 4" PLUS 40/185	SCM 4" PLUS 40/240	SCM 4" PLUS 55/50	SCM 4" PLUS 55/80	SCM 4" PLUS 55/105	SCM 4" PLUS 55/160	SCM 4" PLUS 55/200	SCM 4" PLUS 55/300
	323	STAGE (INTERMEDIATE ~)KIT	242	BUSHING (INTERMEDIATE SUPPORT ~)											
			244	BEARING (INTERMEDIATE SUPPORT BRONZE ~)											
			241	SUPPORT (INTERMEDIATE ~)											
			243	O-RING (INTERMEDIATE SUPPORT ~)											
	325	FILTER (COMPLETE ~)	240	SCREW (WIRE COVER ~)						ZBR29330					
			120	FILTER											
	331	VALVE KIT	167	VALVE (CHECK ~)						ZBR28840					
	372	HYDRAULIC KIT	9	DIFFUSER											
			21	IMPELLER											
			234	RING (ANTI-WEAR ~)	ZBR28870								ZBR28880		
			13	CAP (DIFFUSER ~)											
	384	PUMP BODY KIT	3	DISCHARGE PUMP BODY						ZBR28830					
	404	SHAFT KIT	133	BUSHING (CERAMIC ~)	ZBR28940	ZBR28950	ZBR28960	ZBR28970	ZBR28980	ZBR28990	ZBR29000	ZBR29010	ZBR29020	ZBR29030	ZBR29040
			231	SNAP RING											
			232	SHAFT											
	405	COUPLING KIT	231	SNAP RING											
			103	COUPLING (MOTOR PUMP ~)											
			236	WASHER (MOTOR / PUMP COUPLING ~)											
			237	SCREW (COUPLING ~)											
	452	HYDRAULIC KIT, FIRST STAGE	9	DIFFUSER											
			502	IMPELLER (SIDE SUCTION ~)											
			234	RING (ANTI-WEAR ~)											
			13	CAP (DIFFUSER ~)											
	468	BEARING (BRONZE ~) KIT	197	SUPPORT (BUSHING ~)											
			233	SNAP RING (BRONZE-BEARING SUPPORT ~)											
			230	BEARING (BRONZE ~)											
			133	BUSHING (CERAMIC ~)											
	472	CAP (DIFFUSER ~)KIT	326	DOUBLE CAP DIFFUSER											
	474	SLEEVE KIT	83	SLEEVE	ZBR29360	ZBR29370	ZBR29380	ZBR29390	ZBR29400	ZBR29410	ZBR29420	ZBR29430	ZBR29440	ZBR29450	ZBR29460
	500	POWER SUPPLY CABLE KIT	499	POWER SUPPLY CABLE											
										ZBR29340 (1)					ZBR29350 (1)
	500	POWER SUPPLY CABLE KIT	499	POWER SUPPLY CABLE											
										ZBR44650 (2)					ZBR44740 (2)
	501	WIRE COVER KIT	239	BRACKET (OMEGA-SHAPE ~)	ZBR29700	ZBR29710	ZBR29720	ZBR29730	ZBR29740	ZBR29750	ZBR29760	ZBR29770	ZBR29780	ZBR29790	ZBR29800
			240	SCREW (WIRE COVER ~)											
			238	COVER (WIRE ~)											




DRW. DR100001

SPARE-PARTS

Select language English

SPARE-PARTS KIT TABLE

SPARE-PARTS				SCM 4" PLUS													
RECOMMEN DED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONE NT REF. Nr.	COMPONENT DESCRIPTION	SCM 4" PLUS	SCM 4" PLUS	SCM 4" PLUS	SCM 4" PLUS	SCM 4" PLUS	SCM 4" PLUS	SCM 4" PLUS	SCM 4" PLUS	SCM 4" PLUS	SCM 4" PLUS	SCM 4" PLUS	SCM 4" PLUS	
					75/40	75/56	75/75	75/110	75/140	75/210	115/30	115/60	115/65	115/95	115/122	115/185	115/245
			242	BUSHING (INTERMEDIATE SUPPORT ~)													
	323	STAGE (INTERMEDIATE ~ KIT	244	BEARING (INTERMEDIATE SUPPORT BRONZE ~)													
			241	SUPPORT (INTERMEDIATE ~)													
			243	O-RING (INTERMEDIATE SUPPORT ~)													
	325	FILTER (COMPLETE ~)	240	SCREW (WIRE COVER ~)													
			120	FILTER													
	331	VALVE KIT	167	VALVE (CHECK ~)													
			9	DIFFUSER													
	372	HYDRAULIC KIT	21	IMPELLER													
			234	RING (ANTI-WEAR ~)													
			13	CAP (DIFFUSER ~)													
	384	PUMP BODY KIT	3	DISCHARGE PUMP BODY													
			133	BUSHING (CERAMIC ~)													
	404	SHAFT KIT	231	SNAP RING	ZBR29050	ZBR29060	ZBR29070	ZBR29080	ZBR29090	ZBR29100	ZBR29110	ZBR29120	ZBR29130	ZBR29140	ZBR29150	ZBR29160	ZBR29170
			232	SHAFT													
			231	SNAP RING													
	405	COUPLING KIT	103	COUPLING (MOTOR PUMP ~)													
			236	WASHER (MOTOR / PUMP COUPLING ~)													
			237	SCREW (COUPLING ~)													
			9	DIFFUSER													
	452	HYDRAULIC KIT, FIRST STAGE	502	IMPELLER (SIDE SUCTION ~)													
			234	RING (ANTI-WEAR ~)													
			13	CAP (DIFFUSER ~)													
			197	SUPPORT (BUSHING ~)													
	468	BEARING (BRONZE ~) KIT	233	SNAP RING (BRONZE-BEARING SUPPORT ~)													
			230	BEARING (BRONZE ~)													
			133	BUSHING (CERAMIC ~)													
	472	CAP (DIFFUSER ~) KIT	326	DOUBLE CAP DIFFUSER													
	474	SLEEVE KIT	83	SLEEVE	ZBR29470	ZBR29480	ZBR29370	ZBR29490	ZBR29500	ZBR29510	ZBR29520	ZBR29360	ZBR29530	ZBR29540	ZBR29550	ZBR29560	ZBR29300
	500	POWER SUPPLY CABLE KIT	499	POWER SUPPLY CABLE													
	500	POWER SUPPLY CABLE KIT	499	POWER SUPPLY CABLE													
			239	BRACKET (OMEGA-SHAPE ~)													
	501	WIRE COVER KIT	240	SCREW (WIRE COVER ~)	ZBR29810	ZBR29820	ZBR29710	ZBR29830	ZBR29840	ZBR29850	ZBR29860	ZBR29700	ZBR29870	ZBR29880	ZBR29890	ZBR29900	ZBR29910
			238	COVER (WIRE ~)													

				DRW. DR100001	SPARE-PARTS															
Select language <input type="text" value="English"/>				SPARE-PARTS KIT TABLE																
SPARE-PARTS				SCM 4" PLUS	PUMP MODEL															
RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	SCM 4" PLUS 150/42	SCM 4" PLUS 150/64	SCM 4" PLUS 150/84	SCM 4" PLUS 150/120	SCM 4" PLUS 150/170	SCM 4" PLUS 150/200	SCM 4" PLUS 150/300	SCM 4" PLUS 250/53	SCM 4" PLUS 250/78	SCM 4" PLUS 250/100	SCM 4" PLUS 250/127	SCM 4" PLUS 250/185				
323		STAGE (INTERMEDIATE - JKIT	242	BUSHING (INTERMEDIATE SUPPORT -)													1 pc			
			244	BEARING (INTERMEDIATE SUPPORT BRONZE -)															1 pc	
			241	SUPPORT (INTERMEDIATE -)																1 pc
			243	O-RING (INTERMEDIATE SUPPORT -)																1 pc
325		FILTER (COMPLETE -)	240	SCREW (WIRE COVER -)														1 pc		
			120	FILTER															1 pc	
331		VALVE KIT	167	VALVE (CHECK -)														1 pc		
			9	DIFFUSER															1 pc	
372		HYDRAULIC KIT	21	IMPELLER														1 pc		
			234	RING (ANTI-WEAR -)														1 pc		
			13	CAP (DIFFUSER -)															1 pc	
			3	DISCHARGE PUMP BODY															1 pc	
384		PUMP BODY KIT	133	BUSHING (CERAMIC -)	1 pc	3 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc		
			231	SNAP RING	3 pc	3 pc	3 pc	3 pc	3 pc	3 pc	3 pc	3 pc	3 pc	3 pc	3 pc	3 pc	3 pc	3 pc	3 pc	
404		SHAFT KIT	232	SHAFT	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	3 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc		
			231	SNAP RING	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	2 pc	
			103	COUPLING (MOTOR PUMP -)																1 pc
			236	WASHER (MOTOR / PUMP COUPLING -)																1 pc
405		COUPLING KIT	237	SCREW (COUPLING -)														1 pc		
			9	DIFFUSER														1 pc		
			502	IMPELLER (SIDE SUCTION -)															1 pc	
			234	RING (ANTI-WEAR -)															1 pc	
452		HYDRAULIC KIT, FIRST STAGE	13	CAP (DIFFUSER -)														1 pc		
			197	SUPPORT (BUSHING -)														1 pc		
			233	SNAP RING (BRONZE-BEARING SUPPORT -)															1 pc	
			230	BEARING (BRONZE -)															1 pc	
468		BEARING (BRONZE -) KIT	133	BUSHING (CERAMIC -)														1 pc		
			326	DOUBLE CAP DIFFUSER															1 pc	
			83	SLEEVE															1 pc	
474		SLEEVE KIT															1 pc			
500		POWER SUPPLY CABLE KIT	499	POWER SUPPLY CABLE	ZBR29580	ZBR29590	ZBR29600	ZBR29610	ZBR29620	ZBR29630	ZBR29640	ZBR29650	ZBR29660	ZBR29670	ZBR29680	ZBR29690	1 pc			
500		POWER SUPPLY CABLE KIT	499	POWER SUPPLY CABLE	ZBR29340 (1)	ZBR44650 (2)			ZBR29350 (1)	ZBR44740 (2)	ZBR44750 (2)	ZBR44650 (2)	ZBR44740 (2)	ZBR29350 (1)			1 pc			
501		WIRE COVER KIT	239	BRACKET (OMEGA-SHAPE -)	2 pc	2 pc	2 pc	2 pc	2 pc	2 pc	2 pc	2 pc	2 pc	2 pc	2 pc	2 pc	2 pc			
			240	SCREW (WIRE COVER -)	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc	4 pc			
			238	COVER (WIRE -)	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc	1 pc			

(1)=Franklin motor
(2)=Pentair motor